

## Re-Useable Cold Packs

Great for use with non-refrigerated carts or for extra protection in extreme conditions

## Eliminate Wet & Dry Ice Hassles Forever

Before each use, freeze the eutectic liquid contained in the plate. To do this, place the plate in a freezer at a temperature at least 10 degrees below the set point of the plate for 24-48 hours until it is completely solid. Handle with care when frozen as it is sensitive to shock. Do not expose to high heat (120 deg F.). Eutectic Plates are available in the following temperatures. Choose plate temperature closest to the temperature of your product.



- +26 Deg F. requires +10 to freeze, Holds Refrigeration temperature for beverages, Green cap.
- +3 Deg F. requires -10 to -15 to freeze, Used for Ices or Frozen Foods, Red cap.
- -6 Deg F. requires –15 to freeze, used for Ice Cream, Yellow cap,
- -12 Deg F. requires -20 or colder to freeze, used for delivery or transport of bulk ice cream, Purple cap.

**Plates GN1/1,** Size: 20.75" x 12.75" x 1", Weight 11 lbs ea. **Plates GN1/2,** Size: 12.75" X 10.5" x 1", Weight 7 lbs

## **PRICING**

UPS Shipping charges additional.

GN1/1, Sold in Boxes of (5) plates @ \$265 per box / or \$53 ea. GN1/2, Sold in Boxes of (10) plates @ \$360 per box / or \$36 ea.

## **QUANTITY PRICING**

Per order / shipment via truck freight / truck freight charges additional.

GN1/1 > (40) pieces / (8) + boxes of (5) plates @ \$215 per box / or \$43 plate.

GN1/2 > (50) pieces / (5) + boxes of (10) plates @ \$300 per box / or \$30 plate.